## **Install PenPower eSignature**

### **Software Installation**

- Insert the installation CD into the CD drive first, and double click the [PenPower\_eSignature.exe] in the CD to start to install.
- 2. Please follow the instructions to continue the installation.
- 3. After installing, please reboot the operating system to complete the installation.

Note: If there is no any [Microsoft .NET Framework 4] suite installed in your computer, PenPower eSignature install program will install the suite automatically. To avoid any error, please make sure the available hard disk space is more than 2GB.

#### **Hardware Installation**

Please plug the L398S tablet into the USB port of computer, the blue LED on the tablet will be bright.


Note: If you are using a USB hub, it is recommended to connect the tablet to a USB hub with an external power source to avoid problems with insufficient power supply.

## Start to Use

- 1. PenPower eSignature program can send your signature to the folloing applications:
- Microsoft Office Word / Excel / Powerpoint
- Adobe Reader DC
- Adobe Sign

Note: Adobe Reader XI v11.0.x are not supported.

2. Double click the [PenPower\_eSignature] shortcut on the desktop to launch the program, and you will see the LCD on the tablet be bright.



3. Now you can start to write on the LCD screen of the tablet, the content you wrote will be displayed synchronously on the PenPower eSignature program.



- 4. After signing, please click on the target application to active, and then click the [OK] button on the program to send the signature to the target application.
- 5. If you want to sign again, please click the [Clear] button on the program to delete the current inking.

Note: When signing on Adobe Reader DC & Adobe Sign application, there is a special operation flow needs to be followed. PenPower eSignature will display the step by step instructions for you to know how to use.



# **Warranty Card**

### Thank you for purchasing PenPower product.

Please register your product on <u>www.penpower.net/reg.html</u> to ensure warranty service:

- 1 Year Warranty
- Software Updates
- Technical Support

#### Note:

- The warranty period begins on the purchase date, standard warranty period ends 12 months after the purchase date.
- Product warranty is limited to the origin of purchase. Users might pay a service fee when requesting warranty service in different country.
- A copy of the official invoice must be submitted as proof of purchase for warranty service.



# **Warranty Card**



Product Name:
Purchase Date:
Dealers Signature

PenPower Technology Ltd.

Global Operations: USA +1-510-897-6600 Beijing +86-10-8287-3871

Taiwan +886-2-2778-1922 Guangzhou +86-20-8776-2205

Hong Kong +852-2111-1548

## **Settings**

To open the Settings window, please click the button on the upper-right corner of program.



In the Settings, you can change the language of user interface, and selecet the width of the signature inking.

If you need the digital version of this using guide, you can download it in the [User Manual] page.

If you are interested in obtaining the signature SDK and developing it, please contact us: **solution\_TW@penpower.net**