

Product Introduction

ViaTalk BT uses the latest Bluetooth BLE technology, whether you are using iOS or Android phone, no complicated installation of software is needed, just plug the smart USB Bluetooth receiver into the computer's USB port, and use the exclusive phone APP which is no need to pair, your talking can be converted into editable texts quickly and sent to Windows or Mac to continue to edit or translate.



Install APP on Smart Phone

© **On Android device** (Download APP via Google Play)

Please search [ViaTalk BT] on Google Play, and click [Install] once found. Or you can use the phone to scan the QR Code below to link to access the installation screen.



© **On iPhone** (Download APP via APP store)

Please search [ViaTalk BT] on APP store, and click [Install] once found. Or you can use the phone to scan the QR Code below to link to access the installation screen.



Install software on PC


Please plug ViaTalk BT USB Bluetooth receiver to the computer, and open ViaTalk BT APP on the phone. Please turn on the Bluetooth function if you were asked to, and the APP will pop up a guideline for software downloads, please follow the steps to download and install the software. Or later you can click [Settings] / [PC software download] in the APP to install the software.

If you cannot properly install with the guidelines, please download the ViaTalk BT PC software via the following URL depending on your computer system.


Windows: <http://mobile.penpower.net/download/VTBTW/>

Mac: <http://mobile.penpower.net/download/VTBTM/>

© Input Mode



© Translation Mode (Not provide on Mac)




1	Input Mode	10	Input language
2	Settings, more information	11	Input/display text area
3	Translation Mode	12	Text output to other software
4	Delete texts (Backspace)	13	Clear text
5	Space input	14	Copy input text
6	Undo	15	Translation language
7	Enter a new line	16	Translation text area display
8	Full/half shape	17	Pronunciation
9	Notations	18	Copy translations

Start to Use

ViaTalk BT requires network connection on your phone and PC, if your phone has network usage restrictions, please switch to Wi-Fi to get better user experience, and also avoid to reduce the network usage after long-term use.


◎ Input Mode



Click [Input] on the PC software, and open the program you want to input, such as WORD, and click the cursor to the input area.

Operation on Android


1. Choose input mode , and tap  to choose language.


2. Tap  and start to talk to the phone's microphone when the microphone icon becomes GREEN. When you stop talking, the icon will turn into RED and process the recognition, please wait till it turns into GREEN to start talk again.

Microphone icon (GREEN): Available to talk.



Microphone icon (RED): Stop talking, busy to recognize.

Tip: You can tap the microphone icon to pause or resume talking anytime.

3. If you want to use the way of typing and transfer texts to the computer, please tap keyboard input mode , then tap the blank area on the phone to launch the keyboard to type.

4. Tap  on the up-right corner to switch auto/manual send word. If set to manual send word, please remember to tap [Submit] to send the recognized words.


Operation on iPhone

1. Choose input mode , and click  on the keyboard to switch the Keyboard Language that you want to use and interpret. If your Siri function is off, please go to [Settings]/ [General]/ [Siri] to turn on the Siri function.

2. If you want to change Keyboard Language in the Input Method, please go to [Settings]/ [General]/ [Keyboard]/ [Keyboard]. You can delete any language's keyboard by clicking [Edit] on the top right of the screen. Or click [Add New Keyboard] below to add more language's keyboard.

3. Click the microphone icon  and speak toward the microphone on the phone.



© **Translation Mode** (Not provide on Mac)



1. Click [Translation] of PC software and select the translation language.
2. Please refer to the operation of the previous [Input] chapter, and the program will automatically send the words from iPhone to the PC, you can see the translation on PC.


Tip: Please input correct notations to get the best translation.

◎ Mouse/Presenter


ViaTalk BT iPhone APP provides mouse  and presenter function . You can take your phone as a mouse to control your PC or take it as a presenter to present without opening any PC software.

Software Settings

◎ Windows


Click  in the upper right corner on ViaTalk BT PC software to configure the software. You can switch the UI display language, change the font size in the text field and turn on/off the automatic software update in the [Settings] page.

If you check [Convert specific symbols], the application will interpret the pronunciation "comma" into ",". More option on the notation pronunciation, please refer to [Symbol/Command list].




© Mac



Click ViaTalk BT icon on the status bar, and click [More] to set whether auto launch the software when the computer finish booting.



If you check [Convert specific symbols], the application will interpret the pronunciation "comma" into ",". More option on the notation pronunciation, please refer to [Symbol/Command list].



© Android / iPhone

Tap the button /  on the up-right corner to open the menu.

● Search Bluetooth receiver

Search and list all the idle ViaTalk BT devices, tap the device which you want to use to connect.

● Forget this device

Tap to forget the connected ViaTalk BT device.

● PC S/W download guide

Open the guide of downloading PC software.

● PC connection test

Tap this item after the Bluetooth connected to check the connection quality with PC is good. If there is no success message pop up on the PC software, please .

● Setting

Open the settings of detection and problem report, etc.

Search bluetooth receiver
Forget this device (3E5B7BE9)
PC SW download guide
PC connection test
Setting